


KUCHT Hood Operation Quick Guide



I. FAN SWITCH:

Motor Speed Adjustment:

Rotate the knob to adjust the motor speed.

The adjustment logic is as follows:



Power Key:

Tap the power key to initiate a 5-minute delay. Tap it again to power off. When the motor is off, touching the power key activates the motor at speed 1.

II. LIGHT SWITCH:

Light Activation:

With the power off, tap the Lamp key to illuminate the lamp at 50% brightness. Tap the key again to turn off the lamp.

Knob Functionality:

With the power off, tap the lamp key to turn on the lamp at 50% brightness. Rotate the knob clockwise to increase brightness and counterclockwise to decrease it. The brightness display adjusts accordingly.

III. STATUS DISPLAY SCREEN:

WHILE POWER IS OFF:

The "Power" key, "Lamp" key, and logo icons are semi-bright.

WHILE POWER IS ON:

All speed icons, the speed key, power key, brightness, logo, and lamp key are fully illuminated. The brightness display corresponds to the selected brightness level.



SCAN THIS QR CODE TO
ACCESS AN INSTRUCTIONAL VIDEO

